

## Digital Thyristor Unit

# DPU(1-phase) Series

## USER MANUAL

CE



**DPU Series**

Thank you very much for selecting Autonics products.

**For your Safety, please read the following before using.**



## Preface

Thank you for purchasing Autonics product.

Please familiarize yourself with the information contained in the Safety Precautions section before using this product.

This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.

## User Manual Guide

- Please familiarize yourself with the information in this manual before using the product.
- This manual provides detailed information on the product's features. It does not offer any guarantee concerning matters beyond the scope of this manual.
- This manual may not be edited or reproduced in either part or whole without permission.
- A user manual is not provided as part of the product package.
- Visit our web site ([www.autonics.com](http://www.autonics.com)) to download a copy.
- The manual's content may vary depending on changes to the product's software and other unforeseen developments within Autonics, and is subject to change without prior notice. Upgrade notice is provided through out Autonics web site.
- We contrived to describe this manual more easily and correctly. However, if there are any corrections or questions, please notify us these on Autonics web site.

## User Manual Symbols

Symbol	Description
 <b>Note</b>	Supplementary information for a particular feature.
 <b>Warning</b>	Failure to follow instructions can result in serious injury or death.
 <b>Caution</b>	Failure to follow instructions can lead to a minor injury or product damage.
 <b>Ex.</b>	An example of the concerned feature's use.
※1	Annotation mark.

## Safety Precautions

- Following these safety precautions will ensure the safe and proper use of the product and help prevent accidents and minimize hazards.
- Safety precautions are categorized as Warnings and Cautions, as defined below:

 <b>Warning</b>	<b>Warning</b>	Cases that may cause serious injury or fatal accident if instructions are not followed.
--	----------------	---

 <b>Caution</b>	<b>Caution</b>	Cases that may cause minor injury or product damage if instructions are not followed.
--	----------------	---



### Warning

- Caution for wiring  
If malfunction or error of this unit cause serious accident, install the external protection circuit properly.  
This unit does not have power switch. Please install an external power switch.  
To prevent electric shock, ground it 1st grounding and supply an electric current to this unit.
- Power  
To prevent damage or malfunction of this unit, supply the rated power to this unit.  
To prevent electric shock and malfunction of this unit, do not supply the power before completing wiring.
- Ban for using in gas  
It is not an explosion structure. Do not use this unit where there are flammable or explosive gases.
- Connections  
Do not disassemble or modify this unit. It may cause malfunction, electric shock, or a fire.  
Do not touch the terminals during power ON. It may cause malfunction, or electric shock.
- Caution for maintenance  
Turn OFF the power before removing this unit. It may cause electric shock, cause malfunction, damage to this unit or electric shock.  
To use this unit safely, it is recommended to maintenance this unit regularly.  
Only for proper usage, the term of guarantee for this unit with accessories is 1 year.
- Environment  
When using this unit indoor, do not use this in the place where electric device is damaged by flammable or explosive gas, high humidity, salinity, dust, etc.



## Caution

- Caution for usage (Do not install this unit at the following places.)
  - The place where ambient temperature is over -10 to 50°C range.
  - The place where ambient humidity is over 5 to 90%RH.
  - The place where temperature changes are rapid and there is dew condensation.
  - The place where there is corrosive gas (especially oil gas, ammonia, etc), or flammable gas.
  - The place where there is vibration or shock to the unit.
  - The place where there is water, oil, drug, or steam.
  - The place where there is lots of dust and dirt, salinity, or iron.
  - The place where big inducement malfunction, static, or magnetism noise occurs easily.
  - The place where there is direct ray of the sun.
  - The place where thermal heat builds up by radiant heat.
  - Do not open the cover automatically to move this unit.
- Installations
  - Tighten this unit with bolts as accessories on the panel.
  - If water enters this unit, you must inspect this unit. It may cause short circuit, or a fire.
  - When installing this unit, use safety protections such as safety shoes, and helmet, etc and be sure that the safety.
  - Be sure that not to put the legs or sit on this unit.
- Temporary storage
  - Fix this unit with transportation screws to store this unit temporarily.
  - Store this unit as below environments.
    - The place where there is no dregs, flammable gas, explosive gas (SO<sub>2</sub>, H<sub>2</sub>SO, etc).
    - The place where there is no vibration, shock
    - The place where there is no steam or not too much hot humidity (95%RH)
    - The place where it is not extreme low temperature (below -20°C)
- Caution for wiring
  - Do not use empty terminals during wiring I/O to other usage.
  - Consider a countermeasure for lots of noises.
- Cleaning
  - In cleaning the unit, use dry cloth.
  - Do not use organic solvent.
  - Turn off the power to clean this unit.

**The specifications, dimensions, etc are subject to change without notice.**



## Table of Contents

Preface .....	iii
User Manual Guide .....	iv
User Manual Symbols .....	v
Safety Precautions .....	vi
Table of Contents .....	ix
Table of Contents .....	x
<b>1. Product introduction .....</b>	<b>11</b>
1.1 Features .....	11
1.2 Ordering information .....	12
1.3 Part descriptions .....	13
<b>2. Specifications .....</b>	<b>15</b>
2.1 Specifications .....	15
<b>3. Dimensions .....</b>	<b>17</b>
<b>4. Connections .....</b>	<b>19</b>
<b>5. Installation and initial operation .....</b>	<b>21</b>
5.1 Installation .....	21
5.2 Initial display .....	21
5.1 Installation .....	21
5.3.1 Parameters .....	21
5.3.2 Monitoring Mode .....	22
5.3.3 Operation Mode[ $\alpha P$ ] .....	23
5.3.4 Setting Mode 1[ $S_E - 1$ ] .....	24
5.3.5 Setting Mode 2[ $S_E - 2$ ] .....	25
<b>6. Parameter setting and functions .....</b>	<b>27</b>
6.1 Control input .....	27
6.2 Functions .....	29
6.2.1 Control method[ $C - \bar{nd}$ ] .....	29
6.2.2 Soft start [ $S_E - t$ ] .....	32
6.2.3 Start limit [ $S_E - L$ ] and start limit time [ $S_E - Lt$ ] .....	33
6.2.4 Output slope setting [ $S_{LoP}$ ] .....	33
6.2.5 Output slope manual adjustment[ $R - GR$ ] .....	34
6.2.6 Base-up [ $b - UP$ ] .....	34

## Table of Contents


6.2.7	Slow up/Slow down.....	35
6.2.8	Output high limit value[H-oL], Output low limit value[L-oL].....	35
6.2.9	Digital input (DI) .....	36
6.2.10	Proportional and integral constant set of feedback control.....	38
6.2.11	Input correction[I-n-b] .....	38
6.2.12	Input slope correction [SPRn].....	39
6.2.13	Display value content selection [dI SP], bar graph content selection [bAr].....	39
6.2.14	Load resistance display method [drE5].....	40
6.2.15	Full load auto recognition [F-Ld].....	41
6.2.16	Parameter lock [LoCt].....	41
<b>6.3</b>	<b>Alarm.....</b>	<b>42</b>
6.3.1	Overcurrent alarm [oC-R].....	42
6.3.2	Current limit [C-Lt] .....	42
6.3.3	Overvoltage alarm [ou-R] .....	43
6.3.4	Fuse disconnection alarm [FUSE] .....	43
6.3.5	Heatsink overheating alarm [HET] .....	43
6.3.6	Element error alarm [SEr] .....	43
6.3.7	Heater disconnection alarm [Hb-R] .....	44
<b>7.</b>	<b>Factory default.....</b>	<b>45</b>
<b>8.</b>	<b>Maintenance.....</b>	<b>47</b>
8.1	Fuse .....	47
8.2	Thyristor (SCR) .....	48
<b>9.</b>	<b>Modbus Mapping Table .....</b>	<b>49</b>
9.1	Function code 3(0X03)=Read holding resistors .....	49
9.2	Function code 4(0x04)=Read input resistors .....	49
9.3	Function code 6(0x06) = write single resistors .....	50
9.4	Function code 16(0x10) = write multiple resistors .....	50
9.5	Address mapping table.....	51
9.5.1	Input resistors .....	51
9.5.2	Holding resistors .....	52

# 1. Product introduction


## 1.1 Features

- Accurate feedback control (static current, static voltage, static power) by RMS measurement
- Phase control and zero-crossing cycle control (fixed/variable cycle) method for various load control
- Remote monitoring and remote control
- Supports Modbus RTU protocol by RS485 communication
- Fast response speed by high-speed CPU
- Built-in customizable 6 digital inputs (DI)
- Basic variable alarm outputs; current error, heater disconnection (heater some disconnection detection), etc.
- Supports multi input of control input signal (current, voltage, potentiometer, etc)
- Enables to install control part separately
- Applicable load: all loads such as super kanthal, platinum, molybdenum, carbon, halogen lamp, chrome, nickel, etc.

## 1.2 Ordering information



## 1.3 Part descriptions



- ① RUN indicator: Turns ON in RUN, turns OFF in STOP.
- ② AUTO indicator: Turns ON in AUTO, turns OFF in MANUAL.
- ③ EVT indicator: Turns ON in Digital Input (DI-1 to 3) ON, flashes in alarm output.
- ④ Display part: Displays selected display value content in RUN mode,  
Displays parameter and set value in SET mode.
- ⑤ V, A indicators: The V indicator turns ON when displaying voltage,  
The A indicator turns ON when displaying current,  
The V, A indicators turn ON when displaying power,  
The V, A indicators turn OFF when displays resistance and input value.
- ⑥ Bar display: Turns ON as 0 to 100% ratio for selected display value.
- ⑦ **M** key: Used to enter parameter mode, monitoring mode and to move between parameters.
- ⑧ **▲**, **▼** key: Used to move setting modes and to set parameters.
- ⑨ **RET** key: Used to return to RUN mode from SET mode



## 2. Specifications

### 2.1 Specifications

Series	DPU
Number of phases	1-phase
Power supply	110VAC / 220VAC / 380VAC / 440VAC (FAN and control power 220VAC 50/60Hz separately)
Allowable voltage	90 to 110% of rated voltage
Rated frequency	50/60Hz (auto recognition), allowable frequency range:±2Hz
Min. load current	1A
Output range	Phase control: 5 to 98%, Z.C. control : 0 to 100%
Control method	<ul style="list-style-type: none"> <li>• Phase control: Normal control(Non-Feedback), static voltage/static current/static power control(Feedback)</li> <li>• Cycle control(Z.C.): Fixed cycle control, Variable cycle control</li> <li>• ON/OFF control(Z.C.)</li> </ul>
Load	<ul style="list-style-type: none"> <li>• Phase control: resistance load, inductive load</li> <li>• ON/OFF, Cycle control: resistance load</li> </ul>
Power consumption	Max. 7W (except FAN operation power)
Display method	<ul style="list-style-type: none"> <li>• Display value and SV display: 7 Segment 4 digit</li> <li>• Status display: 4 LED</li> <li>• Display value percentage display: 11 LED Bar</li> </ul>
Output accuracy	<ul style="list-style-type: none"> <li>• Static voltage feedback control: Within ±3% F.S. of rated voltage (within variable ±10% F.S. of rated voltage)</li> <li>• Static current feedback control: Within ±3% F.S. of rated voltage (within variable 1 to 10 times of rated resistance)</li> <li>• Static power feedback control: Within ±3% F.S. of rated voltage (within variable ±10% F.S. of rated voltage and within variable 1 to 10 times of rated resistance)</li> <li>• Normal control: within ±10% F.S. of rated voltage</li> </ul>
Set method	By front keys, By communication
Control input	<ul style="list-style-type: none"> <li>• Auto: 4-20mA / 0-20mA / 0-5VDC / 1-5VDC / 0-10VDC / voltage pulse(0/12VDC) / no-voltage input(ON/OFF) / communication input (RS485)</li> <li>• Manual: Internal 10kΩ VR, External 3 to 10kΩ VR (min. 2W)</li> </ul>
Digital input(DI)	AUTO/MAN switching, RUN/STOP switching, RESET, Output holding, SP setting (SP1 to 6)
Display content	Control input, load voltage, load current, load power, load resistance, power supply frequency
Min. display output	Min. 2.5% of rated voltage/current
Option output	RS485 communication output(Modbus RTU method), [max. 32 units]
Dielectric strength	2,000VAC 50/60 Hz for 1 min.(between input terminal and power terminal)
Vibration	0.75mm amplitude at frequency of 5 to 55Hz (for 1 min.) in each of X, Y, Z directions for 2 hours
Insulation resistance	Min. 200MΩ(at 500VDC megger)
Noise resistance	Square shaped noise by noise simulator (pulse width 1μs) ±2kV
Environment	Ambient temp.
	-10 to 50°C, storage : -20 to 80°C
Approval	Ambient humi.
	5 to 90%RH
Unit weight	<ul style="list-style-type: none"> <li>• A Size: 3.0kg</li> <li>• B Size: 5.5kg</li> <li>• C Size: 11.0kg</li> <li>• D Size: 17.5kg</li> </ul>


※Environment resistance is rated at no freezing or condensation.

**Communication specifications**

Application standard	Compliance with EIA RS485
Max. connections	64 channels(address : 01 to 64, auto set)
Communication type	2-wire half duplex
Synchronization method	Asynchronous
Communication distance	Max. 800m
Communication speed	38,400 bps
Communication response time	5 to 99ms
Start bit	1bit (fixed)
Data bit	8bit (fixed)
Parity bit	None(fixed)
Stop bit	2bit(fixed)
Protocol	ModBus RTU(×1 character = fixed 11bit)


### 3. Dimensions

(1) A Size: DPU1□A-25 / 40 / 50 / 70




※25A, 40A, 50A are not attached a fan.


(2) B Size : DPU1□B - 80 / 100 / 120 / 150 / 180 / 200





## (3) C Size: DPU1□C - 250 / 350




## (4) D Size : DPU1□D - 400 / 500 / 600



※ In case of remote display unit + RS485 communication option,




## ● Panel cut-out




It is recommended for remote panel cable to use max. 5 m to prevent noise. (Check the length when ordering it.)

## 4. Connections


• A Size




• B Size




• C Size



• D Size





- ※1. Do not mix noise to input cable.  
It is recommended to use shield cable,  
twisted cable as input cable for effective noise.
- ※2. If there is possible to affect inductive noise,  
it is recommended to use shielded cable at high-frequency power for effective noise.
- ※3. DI input switch should be for low current and ON resistance should be max. 20Ω (including cable  
resistance).
- ※4. DI input terminals are COM, DI-1 to 3, RUN, AUTO.
- ※5. For remote display unit option model,  
use connection cable as our standard cable.
- ※6. When connecting ⑥, ⑪ , it operates as MANUAL. When connecting, ⑥, ⑦, ⑪,  
it operates AUTO.

## 5. Installation and initial operation


### 5.1 Installation

Turn OFF the main power and open the front cover.

Wire it according to the connection diagrams.


### 5.2 Initial display

When turning ON the power to the unit, front displays flash for 1 sec and it displays product version, rated voltage, rated current and operates RUN mode.




### 5.1 Installation

#### 5.3.1 Parameters





Mode	Descriptions
Monitoring Mode	Monitors input value, load voltage/current/power/resistance, power frequency.
Operating Mode[ $\alpha P$ ]	Sets parameters for DPU operation
Setting Mode 1[5t-1]	Sets parameters for details set.
Setting Mode 2[5t-2]	Sets parameters for alarm

### 5.3.2 Monitoring Mode




### 5.3.3 Operation Mode[ $\square P$ ]



5.3.4 Setting Mode 1[ $S\bar{E}-1$ ]

## 5.3.5 Setting Mode 2[5E-2]





## 6. Parameter setting and functions

### 6.1 Control input

#### (1) Input type

Type					Parameter
AUTO input	Analog input	Current	4-20mA	Input impedance 100Ω	4-20
			0-20mA		0-20
		Voltage	1-5VDC	Input impedance 25Ω	1-5
			0-5VDC		0-5
			0-10VDC		0-10
	ON/OFF input	Voltage pulse	0/12VDC	—	55r
		No-voltage pulse	ON/OFF		—
	Com. input	RS485	—	—	Com
MANUAL input		Internal VR	10kΩ	—	—
		External VR	3 to 10kΩ	—	—

#### (2) Input selection

In AUTO input, select it at control input type [I - P] at setting mode1.

In MANUAL input, set output slope manual adjustment [R - RA] in operating mode as OFF and select the input by the inner 3-level slide switch.

- Output slope manual adjustment [R - RA] setting as OFF: Select the input by the inner 3-level slide switch.

Type	Description
MAN INT	Adjust output slope with the internal VR
MAN EXT	Adjust output slope with the external VR
AUTO	No function

AUTO/MANUAL selection is available by no.7 and 11 terminals. ON setting is for AUTO input drive and OFF setting is for MANUAL input drive. When AUTO/MANUAL terminal input is OFF, internal AUTO/MANUAL selection switch is available only for setting MAN INT, and MAN EXT.

**(3) RMS display**

This unit measures and displays RMS for accuracy.

At pure resistance load, in normal control, when input is 4-20mA and rating is 220V, it displays as below.

Input	4mA	8mA	12mA	16mA	20mA
MV	0%	25%	50%	75%	100%
Display voltage	0.0V	70V	155.5V	209.7V	220.0V

In case of static voltage or static current, voltage and current displays as below.

Input	4mA	8mA	12mA	16mA	20mA
MV	0%	25%	50%	75%	100%
Display voltage (static voltage control)	0.0	55.0	110.0	165.0	220.0
Display voltage (static current control)	0.0	12.5	25.0	37.5	50.0


## 6.2 Functions

### 6.2.1 Control method [ $\square - \bar{n}d$ ]

Control method	Control mode	Parameter
Phase control	Normal mode	$PR$
	Static voltage mode	$U-F_b$
	Static current mode	$C-F_b$
	Static power mode	$Y-F_b$
Cycle control	Fixed cycle control	$F-CY$
	Variable cycle control	$U-CY$
	ON/OFF control	$onof$


#### (1) Normal mode [ $PR$ ]

It is general output method to divide control angle proportionally according to control input signal and to output it. The below figure is for output characteristics. It may cause lack power and overpower based on the center of control input.




#### (2) Static voltage mode [ $U-F_b$ ]

At low temperature coefficient load(iron, chrome, nichrome, etc) of electrical resistance, it outputs constant output which is proportion to control input not to change output voltage for power supply variation, load resistance variation.




**(3) Static current mode [E - F b]**

If temperature coefficient of load (platinum, molybdenum, tungsten, etc) changes 6 to 12 times based on room temperature, it outputs constant current which is proportion to control input not to change output voltage for power supply variation, load resistance variation.

**(4) Static power mode [F - F b]**

It outputs constant power which is proportion to control input even though load variation and power supply variation. It is proper control method for a heater which resistance value variation by carbide(SIC) heating is big.




Output characteristics is proper 50% of the curve which connects the point (A) [output voltage 100%  $\times$  output current 50%] and the point (B) [output voltage 50%  $\times$  output current 100%].

The current output capacity of this unit should be over two times of load capacity.


**(5) Fixed cycle control [F-CY]**

During fixed cycle (60 cycles) of load power, it repeats ON/OFF cycle as constant ratio according to control input signal and controls the power supplies on the load.

- Fixed cycle (60 cycles) control – When controlling output as 40%




- Fixed cycle (60 cycles) control – When controlling output as 90%

**(6) Variable cycle control [U-CY]**


Variable cycle control controls required power using min. cycles of AC sine wave according to control input signal and optimize temperature changes of the subject.

- Variable cycle control – When controlling output as 30%




- ON/OFF control method [OnOff]

The method when control input is OFF, output is OFF(0%), when it is ON, output is ON(100%). (same as SSR)



## 6.2.2 Soft start [SS-T]

When controlling the load which has inrush current (platinum, molybdenum, tungsten, infrared lamp, etc) in power ON, or when control input changes rapidly, it prevents the load to increase output gradually within the set time. Set the time for soft start.



Regardless of control method setting (phase control or cycle control), it operates as phase control.

It operates when it is RUN mode from STOP status after supplying power or reset. (when it reaches to the target output value, soft start function ends.)

When the target output is 0%, (control input 0%), soft start function does not operate.

- Set range: 0 to 100 (unit: %)




### Ex.

Soft start set time ( $t$ ) is the time up to 100% increase of output applied to load. When the final target output value is 50%, taken time to reach is  $t/2$ .

Reaching time to the final target output value = target output (%)  $\times$   $t$   
 If soft start time is 25 sec., final target output is 80%,  
 reaching time to the final target output value is  $0.8 \times 25 = 20$ .

### 6.2.3 Start limit [ $S-L_{\text{st}}$ ] and start limit time [ $S-L_{\text{t}}$ ]

When power is ON, changing to RUN status from STOP status, or alarm reset, set limit output value and time to prevent the inrush current or error current.



A: Soft start [ $S-L_{\text{st}}$ ] function ends

B: Slow up [ $U_P-L_{\text{t}}$ ] function ends

C: Slow down [ $d_n-L_{\text{t}}$ ] function ends

Regardless of control method setting (phase control or cycle control), it operates as phase control.


- Start limit [ $S-L_{\text{st}}$ ] set range: 0 to 110 of output (unit: %)

- Start limit time [ $S-L_{\text{t}}$ ] set range: 0 to 100 sec.(unit: sec.)

### 6.2.4 Output slope setting [ $SLOP$ ]

This function is to set output changed ratio by control input from 0.00 to 1.00 range.


Output value when setting slope is input(%) X slope value.



## 6.2.5 Output slope manual adjustment [R-GA]

This function is to adjust manually (internal or external VR) output value ratio for control input.

When setting AUTO GAIN function as ON in AUTO operation, [ $SL\triangle P$ ] is not displayed. It displays slope value by the internal or external VR input.




- Output slope manual adjustment [R-GA] setting as ON: Set output slope by the inner 3-level slide switch

Type	Description
MAN INT	Adjust output slope with the internal VR
MAN EXT	Adjust output slope with the external VR
AUTO	No function

## 6.2.6 Base-up [B-UP]

This function is to add base-up set value to input signal.

It is available only when output low-limit value is 0%.



When setting base-up, output value is input (%) X slope value + base-up set value. It is limited by start limit value at initial start.


- Set range: Base-up set value (%) < Output high-limit value

### 6.2.7 Slow up/Slow down

It is same purpose as soft start function.

Soft start starts only one time at first but slow up/slow down function start during operation.

Regardless of control method setting (phase control or cycle control), it operates as phase control.




A : Soft start ends, B : Slow up ends, C : Slow down ends

When it reaches to the target output value, slow up/slow down functions end. When it sets as '0', slow up/slow down do not operate.

- Set range: 0 to 100 (unit: sec.)

### 6.2.8 Output high limit value [ $H - oL$ ], Output low limit value [ $L - oL$ ]

This function is to high/low limit output range to protect load.




- Set range: 0 < output low limit value < output high limit value < 100 (unit: %)

## 6.2.9 Digital input (DI)

Below functions are available by terminal input.

Digital input has five terminals; AUTO/MANUAL terminal, RUN/STOP terminal, and DI-1 to 3 terminals. Select the function for each input terminal of DI-1 to 3.



### (1) AUTO/MANUAL selection [no.7 – no.11 terminals]

Select AUTO(close)/MANUAL(open) input by terminal input.

AUTO mode controls output according to control input as analog input (voltage, current) or ON/OFF input (including SSR pulse input).

MANUAL mode controls according to control input as the internal VR adjustment or the external VR adjustment.

When selecting AUTO (close), the front AUTO indicator turns ON or selecting MANUAL(open), the front AUTO indicator turns OFF.

### (2) Run/Stop switching digital input [no.6 – no.11 terminals]

Select RUN(close)/STOP(open) operation status by terminal input.

RUN mode operates as the set contents by control input. STOP mode is standby status.

When selecting RUN(close), the front RUN indicator turns ON or selecting STOP(open), the front RUN indicator turns OFF.

### (3) Digital input(DI1 to DI3) settings

Select the each function for each digital input.

When setting ON(close) to DI input, the front EVT indicator turns ON or setting OFF(open), the front EVT indicator turns OFF.

- Multi SP[SP - ̄]


It is available to set total 6 SPs. When selecting [SP - ̄] at [DI - 1], [DI - 2] and [DI - 3] parameters are not displayed and 6 parameters SP1 to SP6 to set SPs are displayed in operating mode.



**Ex.**

	di - 1	di - 2	di - 3	Operating mode SP value set parameter
A	○	X	X	SP - 1 (20%)
B	X	○	X	SP - 2 (40%)
C	○	○	X	SP - 3 (60%)
D	X	X	○	SP - 4 (80%)
E	○	X	○	SP - 5 (100%)
F	X	○	○	SP - 6 (0%)
G	○	○	○	—

○: Close, X: Open



※ A, B, C, D, E, F  
: Close/Open status of Digital Input


- Single SP[SP-1, SP-2, SP-3]

For single SP, set SP-1, SP-2, SP-3 to each digital input for output to reach to the relevant SP. It is available to set individually and duplicated and it is relevant with setting point [SP1 to SP3].



**Ex.**

di - 1	di - 2	di - 3	Operation Mode Setting point1 to 3 [SP1 to SP3] parameter
SP-1	SP-2	SP-3	SP-1(ex:20%)
			SP-2(ex:40%)
			SP-3(ex:60%)



- RESET[RESET]

After selecting RESET function, turn digital input ON(close) and open, this unit resets and re-starts.

- HOLD[HOLD]

After selecting HOLD function and digital input is ON(close), output and display value of this unit is hold. (it operates hold when digital input maintains ON(close) status.)

### 6.2.10 Proportional and integral constant set of feedback control

Proportional integral control: This is the combination of proportional control and integral control.

Proportional control operates soft control without overshoot and hunting for the set value.

Integral control modifies offset automatically to reach the set value stably.

The optimal values of proportional constant and integral constant are set as factory defaults.

When changing proportional constant and integral constant, it may cause response delay in feedback control or overshoot or hunting.

Proportional constant set[P], integral constant set [I] parameters are displayed when control mode is static voltage, static current, static power mode in phase control.

#### (1) Proportional constant set [P]

It compensates error from the target value proportionally.

If proportional constant value is small, response is fast and it may cause overshoot or hunting. If proportional constant value is big, response is slow.

- Set range: 0(0%) to 2000(100%)

#### (2) Integral constant set [I]

It compensates cumulative error from the target value.

The set integral constant is the time when proportional value and integral value are equal.


If integral constant value is small, response is fast and it may cause overshoot or hunting.

If integral constant value is big, response is slow.

- Set range: 0.1 to 999.9 (unit: sec.)

### 6.2.11 Input correction[I n - b]

It compensates the offset between actual input value and measured input value.




#### Ex.

Input type is 4 to 20mA,

When 4mA is applied and the input monitor value displays 0.5%, set  $I\ n - b$  as -0.5 and the input monitor value displays as 0.0%.

### 6.2.12 Input slope correction [*SPRn*]

It compensates the slope of the measured 100% input for actual 100% input value.



**Ex.** Input type is 4 to 20mA.

When 20mA is applied and the input monitor value displays 99.5%, set *SPRn* as 0.5 and the input monitor value is 100.0%.

- Set range: -99.9 to 99.9 (unit: %)

### 6.2.13 Display value content selection [*d1 SP*], bar graph content selection [*bGr* ]

You can select display value content for the display part and bar graph in RUN mode.

- Display range: load voltage [*L d - U*], load current [*L d - R*], power [*W*], control input [*- EF*]

### 6.2.14 Load resistance display method [ $d_{rE5}$ ]

This function is for display load resistance [ $rE5$ ] into a percentage in monitoring mode when disconnecting the parallel load. You can select this value as increase rate of load resistance [ $UP$ ] or as decrease rate of number of loads [ $d_{oUn}$ ].




#### Note

Decrease rate of number of loads [ $d_{oUn}$ ] displays correct decrease rate only when the connected each load resistance is same.



#### Ex.

$R_1$  to  $R_{10}$  = 10Ω of each and load resistance ( $R$ ) = 1Ω  
When disconnecting  $R_1$  to  $R_5$ ,



① Increase rate of load resistance [ $UP$ ]

It is based on 100% of load resistance( $R$ ), 1Ω . When disconnected  $R_1$  to  $R_5$ , load resistance is 2Ω and load resistance [ $rE5$ ] in monitoring mode displays 200%.

② Decrease rate of number of loads [ $d_{oUn}$ ]

It is based on 100% of 10 loads ( $R_1$  to  $R_{10}$ ). When disconnected  $R_1$  to  $R_5$ , the number of load are 5( $R_6$  to  $R_{10}$ ) and load resistance [ $rE5$ ] in monitoring mode displays 50%.

### 6.2.15 Full load auto recognition [F-Ld]

When operating load recognition function, it outputs 100% for 3 sec. Do not use this unit to the device which has problem 100% output of load.

Set F-Ld as on in Setting Mode 1 [5E-1] group and press the M key, load auto recognition function operates. According to secular changes of the load, execute this function regularly.



#### Note

Be sure that when auto recognition starts, it operates 100% output for 3 sec.



#### Caution

Do not execute this function as on without profession's consultations. When executing this function, voltage, current outputs fully. Be sure that it may cause damage to the load.

When using special load using low voltage and high current such as (super)tantalum, SiC, molybdenum, tungsten, etc, it may cause heater disconnect alarm [H-bE].

This alarm does not have problem in operation but it occurs when it does not detect the load when using as low voltage. Set the below notes to clear the alarm.



#### Note

When using special load such as (super) tantalum, SiC, molybdenum, tungsten, [H-bE] alarm clear method:

- Set load resistance display method [DrE5] as UP in Setting Mode 1 [5E-1].
- Set heater disconnect alarm value [Hb-u] as 500 in Setting Mode 2 [5E-2].

### 6.2.16 Parameter lock [LoC#]

This function is to limit parameter set value check and change.

	oFF	LoC1	LoC2	LoC3
Operating Mode set group	●	●	●	○
Setting Mode 2 set group	●	●	○	○
Setting Mode 1 set group	●	○	X	X

●: Enable to check and set, ○: Enable to check/Disable to set, X: Disable to check

## 6.3 Alarm

Alarm	Display	Operation in alarm	Alarm clear
Overcurrent alarm	$\square - C$	Stops output (SCR OFF)	<ul style="list-style-type: none"> <li>• Re-supply the power.</li> <li>• RESET (REF key)</li> <li>• Switch to STOP mode</li> </ul>
Overtoltage alarm	$\square - U$		
Fuse break alarm	$FUSE^{\times 1}$		
Heatsink overheat alarm	$TEHP$		
Element error alarm	$SEr^{\times 1}$		
Heater break alarm	$H- bR$	Continues operation	Automatically cleared within the set range

※1: When it cannot return by re-supplying power because fuse is disconnected or element is error, refer to '8. Maintenance'.

### 6.3.1 Overcurrent alarm [ $\square C - R$ ]

When overcurrent alarm occurs, output stops and alarm maintains.  $\square - C$  flashes for 0.5 sec in the display part and the EVT indicator flashes for 0.5 sec.

When setting as  $[nnn]$ , alarm output does not occur but  $\square - C$  flashes.

Alarm clears when re-supplying power, reset, or stop the unit.

#### (1) Overcurrent alarm value setting [ $\square C - U$ ]

Set overcurrent alarm value within 0.0 to 120.0% of rated current range.

#### (2) Overcurrent alarm delay time [ $\square C - t$ ]

Set overcurrent alarm delay time within 0 to 100 sec. range. After the set time, over current alarm occurs.

### 6.3.2 Current limit [ $C - L \bar{r}$ ]

This function limits current when using big inrush load to protect thyristor.

Especially for voltage feedback, current for load resistance value flows and it may over the rated thyristor only voltage control. Therefore, it limits current to prevent over the rated current.

- Set range: 0 to 110% (unit: %)

### 6.3.3 Overvoltage alarm [ $\text{Ov-U}$ ]

When overvoltage alarm occurs, output stops and alarm maintains.

[ $\text{Ov-U}$ ] flashes for 0.5 sec. in the display part and the EVT indicator flashes for 0.5 sec.

Alarm clears when re-supplying power, reset, or stop the unit.

#### (1) Overvoltage alarm value setting [ $\text{Ov-U}$ ]

Set overvoltage alarm value within 0.0 to 120.0% of rated voltage.

#### (2) Overvoltage alarm delay time [ $\text{Ov-t}$ ]

Set overvoltage alarm delay time within 0 to 100 sec. range. After the set time, overvoltage alarm occurs.

### 6.3.4 Fuse disconnection alarm [ $\text{FUSE}$ ]

When fuse disconnection alarm occurs, output stops. [ $\text{FUSE}$ ] flashes for 0.5 sec. in the display part and the EVT indicator flashes for 0.5 sec.

Alarm clears when re-supplying power, reset, or stop the unit.

### 6.3.5 Heatsink overheating alarm [ $\text{HEAT}$ ]

When the temperature of a heat sink is over 75°C, heat sink overheating alarm occurs. [ $\text{HEAT}$ ] flashes for 0.5 sec. in the display part and AL1 or AL2 indicator turn ON. When heatsink overheating alarm occurs, output stops and alarm maintains. Alarm clears when re-supplying power, reset, or stop the unit after cooling a heatsink.

### 6.3.6 Element error alarm [ $\text{SER}$ ]

Even though output is 0% and 10% of rated current or over current flows for over 3 sec. (or over 5 cycle) continuously, element error alarm occurs.

When element error alarm occurs, output stops and alarm maintains. [ $\text{SER}$ ] flashes for 0.5 sec. in the display part and the EVT indicator flashes for 0.5 sec.

Alarm clears when re-supplying power, reset, or stop the unit.

### 6.3.7 Heater disconnection alarm [Hb - R]

When load resistance display method is set as [UP], it is over the set value, this alarm occurs.

[Hb - R] and display value flashes for 2 sec. in turn in the display part and EVT indicator flashes for 0.5 sec.

Even though heater disconnect alarm occurs, control operation continues.

It is cleared automatically when the value is below the SV of heater disconnect alarm value.

#### (1) Heater disconnection alarm value setting [Hb - u]

Regardless of control method (phase control, cycle control), it operates. For the operation, over 10% of control output (phase control, cycle control) and over 30% of rated current are required.


- Set range: 10 to 500 (unit: %)

Hysteresis of heater disconnect alarm is fixed as 1% for ON/OFF interval.



**Ex.**

When SV for heater disconnect alarm is 50%, alarm turns ON at 50%, alarm turns OFF at 49%.



#### (2) Heater disconnection alarm delay time [Hb - E]

When load resistance display method is set as [down] and load resistance value is under the SV of [Hb - u], alarm disconnection alarm occurs after the set delay time.

- Set range: 0, 1, 2, 3, 5, 10, 20, 30 (unit: sec.)

## 7. Factory default

### (1) Operation mode

Parameter	Default	Parameter	Default
S-L-t	0000	b-UP	0000
S-L-n	I10.0	UP-t	0003
S-L-E	0000	dN-t	0003
R-GA	0FF	L-oL	0000
SLoP	I10.0	H-oL	I10.0
C-L-n	I10.0	SP5	0000
SP1	0000	SP6	0000
SP2	0000	P	0150
SP3	0000	I	020.0
SP4	0000		

### (2) Setting mode 1

Parameter	Default	Parameter	Default
I-n-P	4-20	drE5	doEn
C-nd	PA	bRr	u
dl-1	SP-n	F-Ld	0FF
dl-2	SP-1	Addr	0001
I-n-b	0000	bRUd	384
SPAn	0000	Eonu	EnR
dl SP	Ld-u	LoCE	0FF

### (3) Setting mode 2

Parameter	Default	Parameter	Default
aC-u	I10.0	FUSE	RL1
aC-t	0005	HEAT	RL1
aC-R	RL1	SCr	RL1
au-u	I10.0	Hb-u	010.0
au-t	0005	Hb-R	RL2
au-R	RL1	Hb-t	30




## 8. Maintenance

### 8.1 Fuse


To prevent accident, replace a fuse every two years.

Turn OFF the power and remove the power to remove the fuse which is in the product.


Fuse position by each model




A type



B type



C type



D type



#### Warning

- Use the designated Fuse.
- After changing the fuse, you must check the fuse is installed correctly.

## 8.2 Thyristor (SCR)

This unit has one SCR element of output part.


It is normal status when the resistance between K and G is 10 to 100Ω during checking SCR elements.

Refer to the below circuit diagram for accurate maintenance.

Assemble this unit as below circuit diagram. (Load indicator turns OFF)

When shorting TEST 1 at gate momentarily, open it to turn ON the load indicator.

When the load indicator does not turn ON, SCR elements are bad conditions.



## 9. Modbus Mapping Table

### 9.1 Function code 3(0X03)=Read holding resistors

#### (1) Request

Master to Slave								
0x01	0x03	0x00	0x00	0x00	0x16	xx	xx	
Add.	Com- mand	Start address		Number of data		CRC 16		
		High	Low	High	Low	High	Low	

#### (2) Response

Slave to Master									
0x01	0x03	0x10	0x03	0xE8	...	0x03	0xE8	xx	xx
Add.	Response command	Number of data	1st data		...	16th data		CRC 16	
			High	Low	...	High	Low	High	Low

#### (3) Error

Slave to Master				
0x01	0x83	xx	xx	xx
Address	Response command	Exception code	CRC 16	

※Exception code

0x01 : Not supported command code.

0x02 : Starting address of required data and transmittable address are different.

0x03 : The number of required data is over than the number of transmittable data.

0x04 : Transmittable data does not process properly.

### 9.2 Function code 4(0x04)=Read input resistors

#### (1) Request

Master to Slave								
0x01	0x04	0x00	0x00	0x00	0x10	xx	xx	
Address	Command	Start address		Number of data		CRC 16		
		High	Low	High	Low	High	Low	

#### (2) Response

Slave to Master									
0x01	0x04	0x10	0x03	0xE8	...	0x03	0xE8	xx	xx
Address	Response command	Number of data	1st data		...	16th data		CRC 16	
			High	Low	...	High	Low	High	Low

#### (3) Error

Slave to Master				
0x01	0x84	xx	xx	xx
Address	Response command	Exception code	CRC 16	

※Exception code

0x01 : Not supported command code.

0x02 : Starting address of required data and transmittable address are different.

0x03 : The number of required data is over than the number of transmittable data.

0x04 : Transmittable data does not process properly.

### 9.3 Function code 6(0x06) = write single resistors

#### (1) Request

Master to Slave							
0x01	0x06	0x00	0x00	0x03	0xE8	xx	xx
Address	Command	Station		Data		CRC 16	
		High	Low	High	Low	High	Low

#### (2) Response

Slave to Master							
0x01	0x06	0x00	0x00	0x03	0xE8	xx	xx
Address	Command	Station		Data		CRC 16	
		High	Low	High	Low	High	Low

#### (3) Error

Slave to Master				
0x01	0x86	xx	xx	xx
Address	Response command	Exception code	CRC 16	

※Exception code

0x01 : Not supported command code.

0x02 : Starting address of required data and transmittable address are different.

0x03 : The number of required data is over than the number of transmittable data.

0x04 : Transmittable data does not process properly.

### 9.4 Function code 16(0x10) = write multiple resistors

#### (1) Request

Master to Slave								
0x01	0x10	0x00	0x00	0x00	0x10	0x20	xx	xx
Address	Command	Start address		Number of data		Number of byte	CRC 16	
		High	Low	High	Low		High	Low

#### (2) Response

Slave to Master							
0x01	0x10	0x00	0x00	0x03	0xE8	xx	xx
Address	Command	Station		Data		CRC 16	
		High	Low	High	Low	High	Low

#### (3) Error

Slave to Master				
0x01	0x90	xx	xx	xx
Address	Response Command	Exception code	CRC 16	

※Exception code

0x01 : Not supported command code.

0x02 : Starting address of required data and transmittable address are different.

0x03 : The number of required data is over than the number of transmittable data.

0x04 : Transmittable data does not process properly.

## 9.5 Address mapping table

### 9.5.1 Input resistors

Address	Item	Factor
300001(0000)	Output voltage	*0.1
300002(0001)	Load current	*0.1
300003(0002)	Power	*0.1
300004(0003)	Load resistance	*0.1
300005(0004)	Power frequency	*0.01
300101(0064)	Product number H	00
300102(0065)	Product number L	00
300103(0066)	Hardware version	10
300104(0067)	Software version	10
300105(0068)	Model name 1	"DP"
300106(0069)	Model name 2	"2-"
300107(006A)	Model name 3	"00"
300108(006B)	Model name 4	" "
300109(006C)	Model name 5	" "
300110(006D)	Model name 6	" "
300111(006E)	Model name 7	" "
300112(006F)	Model name 8	" "
300113(0070)	Model name 9	" "
300114(0071)	Model name 10	" "
300115(0072)	Reserved	Reserved
300116(0073)	Reserved	Reserved
300117(0074)	Reserved	Reserved
300118(0075)	Coil start address	0
300119(0076)	Coil quantity	0
300120(0077)	Input start address	0
300121(0078)	Input quantity	0
300122(0079)	Holding reg start address	0
300123(007A)	Holding reg quantity	32
300124(007B)	Input reg start address	0
300125(007C)	Input reg quantity	5

**9.5.2 Holding resistors**

Address	Item	Factor
400001(0000)	Reference value	*0.1(1 to 1000)
400002(0001)	Start time	0 to 99
400003(0002)	Start limit	*0.1(1 to 1000)
400004(0003)	Soft start time	0 to 99
400005(0004)	Output high-limit	*0.1(1 to 1000)
400006(0005)	Output low-limit	*0.1(1 to 1000)
400007(0006)	Remote SP1	*0.1(1 to 1000)
400008(0007)	Remote SP2	*0.1(1 to 1000)
400009(0008)	Remote SP3	*0.1(1 to 1000)
400010(0009)	Remote SP4	*0.1(1 to 1000)
400011(000A)	Remote SP5	*0.1(1 to 1000)
400012(000B)	Remote SP6	*0.1(1 to 1000)
400013(000C)	Slow up time	0 to 99
400014(000D)	Slow Stop time	0 to 99
400015(000E)	Current limit	*0.1(1 to 2000)
400016(000F)	Over current value	*0.1(1 to 1100)
400017(0010)	Over current time	0 to 99
400018(0011)	Over voltage value	*0.1(1 to 1100)
400019(0012)	Over voltage time	0 to 99
400020(0013)	Load detector alarm value	*0.1(1 to 2000)
400021(0014)	Display selected contents	0 to 3
400022(0015)	Bar graph's content	0 to 3
400023(0016)	Control integer KP value	1 to 9999
400024(0017)	Control integer KI value	*0.1(1 to 999.9)
400025(0018)	Control method	0 to 6
400026(0019)	Digital input 1	0 to 4
400027(001A)	Digital input 2	0 to 4
400028(001B)	Digital input 3	0 to 4
400029(001C)	Auto ref input selector	0 to 3
400030(001D)	Load resistance display method	0 to 1

Address	Item	Factor
400031(001E)	Operation	Bit0... Fault Bit1... I-OC Bit2... Over current Bit3... Over volt Bit4... Over temperature Bit5... Fuse cut Bit6... Phase loss Bit7... Load open Bit8... Over SCR Bit9... Over Frequency Bit10... Run/Stop Bit11... Auto/Manual Bit12... EMS Power Bit13... Not Load
400032(001F)	Output slope (%)	*0.001(0 to 1.000)
400033(0020)	Output (%) for input 0%	*0.01(0 to 1000)
400034(0021)	Input correction	*0.1(-999 to 999)
400035(0022)	Input slope correction	*0.1(-999 to 999)
400036(0023)	Overcurrent alarm output	0 to 2 (*1)
400038(0025)	Oversupply alarm output	0 to 2
400039(0026)	Burn out fuse alarm	
400041(0028)	Heat sink temperature abnormal condition alarm	
400042(0029)	Element error alarm	
400044(002B)	Heater break alarm	



## Distributor

# Autonics

Sensors & Controllers

[www.autonics.com](http://www.autonics.com)

### ◎ Headquarters

18, Bansong-ro 513beon-gil, Haeundae-gu, Busan, Korea

### ▣ Overseas Sales Dept.

#402-404, Bucheon Techno Park, 655, Pyeongcheon-ro, Wonmi-gu, Bucheon, Gyeonggi-do, Korea  
Tel: 82-32-610-2730 / Fax: 82-32-329-0728 / E-mail: sales@autonics.com

### ■ Brazil Autonics do Brasil Comercial Importadora Exportadora Ltda

Tel : 55-11-2307-8480 / Fax: 55-11-2309-7784/ E-mail: vendas@autonics.com.br

### ■ China Autonics electronic(Jiaxing) Corporation

Tel: 86-21-5422-5969 / Fax: 86-21-5422-5961 / E-mail: china@autonics.com

### ■ India Autonics Corporation - India Liaison Office

Tel : 91-22-2781-4305 / Fax : 62-21-8088-4440 / E-mail: india@autonics.com

### ■ Indonesia PT. Autonics Indonesia

Tel: 62-21-8088-8815 / Fax: 62-21-658 66 741 / E-mail: indonesia@autonics.com

### ■ Japan Autonics Japan Corporation

Tel: 81-265-79-8570 / Fax: 81-265-79-2442 / E-mail: support@autonicsjp.co.jp

### ■ Malaysia Mal-Autonics Sensor Sdn. Bhd.

Tel : 60-3-7805-7190(Hunting) / Fax : 60-3-7805-7193 / E-mail: malaysia@autonics.com

### ■ Mexico Autonics Mexico Sales Office

Tel : 52-55-5207-0019 / Fax : 52-55-1663-0712 / E-mail: ventas@autonics.com

### ■ Russia Autonics Corp. Russia Representative Office

Tel/Fax: 7-495-660-10-88 / E-mail : russia@autonics.com

### ■ Turkey Autonics Otomasyon Ticaret Ltd. Sti.

Tel : 90-216-365-9117(9113, 9114) / Fax : 90-216-365-9112 / E-mail : info@autonics.com.tr

### ■ USA Autonics USA, Inc.

Tel: 1-847-680-8160 / Fax: 1-847-680-8155 / E-mail: sales@autonicsusa.net

### ■ Vietnam Autonics Vietnam Representative Office

Tel : 84-8-3771-2662 / Fax: 84-8-3771-2663 / E-mail: vietnam@autonics.com

### Major products –

- Photoelectric sensors •Fiber optic sensors •Door sensors •Door side sensors •Area sensors •Proximity sensors •Pressure sensors
- Rotary encoders •Connectors/Sockets •Temperature controllers •Temperature/Humidity transducers •SSR/Power controllers
- Counters/Timers•Panel meters •Tachometer/Pulse(Rate)meters •Display units •Sensor controllers •Switching mode power supplies
- Control switches/Lamps/Buzzers •I/O Terminal Blocks & Cables•Stepper motors/drivers/motion controllers •Graphic/Logic panels
- Field network devices•Laser marking system(Fiber, CO<sub>2</sub>, Nd:YAG) •Laser welding/soldering system
- Recorders•Indicators •Converters •Controllers-Thyristor units •Pressure transmitters •Temperature transmitters