

5-Phase Stepper Motor Driver(1.4A/Phase, DC Power, Multi-Axis)

◎ Function selection DIP switch

	No	Name	Function	Switch position	
	1	TEST	Self diagnosis function	30rpm rotation	ON
	2	1/2 CLK	Pulse input method	1-pulse input method	2-pulse input method
	3	C/D	Auto Current Down	Not use	Use

● TEST

- Self diagnosis function is for motor and driver test.
- This function makes the motor rotate with 30rpm in full step. Rotation speed varies with resolution settings.
- Rotation speed = 30rpm/resolution
- In 1-pulse input method, it rotates to CCW, and in 2-pulse input method, it rotates to CW.
- ※Be sure that the TEST switch is OFF before supplying the power.
- If the TEST switch is ON, the motor operates immediately and it may be dangerous.

● 1/2 CLK

- 1/2 CLK switch is to select pulse input method.
- 1-pulse input method: CW → operating rotation signal input, CCW → rotation direction signal input ([H]: CW, [L]: CCW)
- 2-pulse input method: CW → CW rotation signal input, CCW → CCW rotation signal input.

● C/D (auto current down)

- This function is to reduce the current provided for motor automatically for preventing severe motor's heat when motor stops.
- If motor RUN pulse is not applied, the current provided for motor reduces as the set STOP current.
- ※Be sure that when motor RUN current is reduced, the stop torque of motor also reduced.
- ※Set the STOP current by the STOP current switch.

◎ Setting RUN current

	S/W No.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
	Current (A/Phase)	1.14	1.25	1.36	1.50	1.63	1.74	1.86	1.97	2.10	2.20	2.30	2.40	2.50	2.60	2.78	2.88


- RUN current setting is for the current provided for motor when the motor runs.
- ※When RUN current is increased, RUN torque of the motor is also increased.
- ※When RUN current is set too high, the heat is severe.
- ※Set RUN current within the range of motor's rated current according to its load.
- ※Change RUN current only when the motor stops.

◎ Setting STOP current

	S/W No	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
	%	27	31	36	40	45	50	54	58	62	66	70	74	78	82	86	90

- STOP current setting is for the current provided for motor when the motor stops for preventing severe motor's heat.
- This setting is applied when using C/D(Current down) function.
- Setting value of STOP current is percentage (%) ratio of the set RUN current.
E.g.) Set RUN current as 1.4A and STOP current as 40%.
STOP current is set as 1.4A×0.4=0.56A
- ※When STOP current is decreased, STOP torque of the motor is also decreased.
- ※When STOP current is set too low, the heat is lower.
- ※Change STOP current only when the motor stops.

◎ Zero point excitation output signal (ZERO OUT) [Option]



- This output indicates the initial step of excitation order of stepping motor and rotation position of motor axis .
- This signal outputs every 7.2° of rotation of the motor axis regardless of resolution.
(50 outputs per 1 rotation of the motor.)
E.g.) Full step: outputs one time by 10 pulses input, 20-division: outputs one time by 200 pulses input.

(A)	Photoelectric Sensors
(B)	Fiber Optic Sensors
(C)	Door/Area Sensors
(D)	Proximity Sensors
(E)	Pressure Sensors
(F)	Rotary Encoders
(G)	Connectors/ Sockets
(H)	Temperature Controllers
(I)	SSRs / Power Controllers
(J)	Counters
(K)	Timers
(L)	Panel Meters
(M)	Tacho / Speed / Pulse Meters
(N)	Display Units
(O)	Sensor Controllers
(P)	Switching Mode Power Supplies
(Q)	Stepper Motors & Drivers & Controllers
(R)	Graphic/ Logic Panels
(S)	Field Network Devices
(T)	Software

MD5-HD14-2X, 3X

Ⓞ HOLD OFF function

- This signal is for rotating motor's axis using external force or used for manual positioning.
 - When hold off signal maintains over 1ms as [H], motor excitation is released.
 - When hold off signal maintains over 1ms as [L], motor excitation is in a normal status.
- ※Must stop the motor for using this function.
 ※Refer to ■ I/O Circuit and Connections.

Ⓞ Setting microstep (Microstep: Resolution)

S/W No	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Resolution	1	2	4	5	8	10	16	20	25	40	50	80	100	125	200	250
Step angle	0.72°	0.36°	0.18°	0.144°	0.09°	0.072°	0.045°	0.036°	0.0288°	0.018°	0.0144°	0.009°	0.0072°	0.00576°	0.0036°	0.00288°

● Setting resolution (MS1)


- The set step angle is dividing basic step angle(0.72°) of 5-phase stepping motor by setting value.
- The calculation formula of divided step angle is as below.

$$\text{Set step angle} = \frac{\text{Basic step angle}(0.72^\circ)}{\text{Resolution}}$$

- When using geared type motor, the angle is step angle divided by gear ratio.
 Step angle / gear ratio = Step angle applied gear
 E.g) $0.72^\circ / 10(1:10) = 0.072^\circ$

※Must stop the motor before changing the resolution.

■ I/O Circuit and Connections




※Power input of 2/3-axis are used as same and I/O terminals are proportional to the number of axes.

5-Phase Stepper Motor Driver(1.4A/Phase, DC Power, Multi-Axis)

■ Dimensions

(unit: mm)


◎ MD5-HD14-2X



※Accessory connector specification

Accessory	Connector		Qty.
	Manufacturer	Model No.	
A Power 2P Housing	Yeonho electronics	YH396-02V	1
B Motor 5P Housing	Yeonho electronics	YH396-05V	2
C Signal 6P Housing	JST	XAP-06V-1	2
— Power/Motor Terminal Pin	Yeonho electronics	YT396	12
— Signal Terminal Pin	JST	SXA -001T-P0.6	12

◎ MD5-HD14-3X



※Accessory connector specification

Accessory	Connector		Qty.
	Manufacturer	Model No.	
A Power 2P Housing	Yeonho electronics	YH396-02V	1
B Motor 5P Housing	Yeonho electronics	YH396-05V	3
C Signal 6P Housing	JST	XAP-06V-1	3
— Power/Motor Terminal Pin	Yeonho electronics	YT396	17
— Signal Terminal Pin	JST	SXA -001T-P0.6	18

- (A) Photoelectric Sensors
- (B) Fiber Optic Sensors
- (C) Door/Area Sensors
- (D) Proximity Sensors
- (E) Pressure Sensors
- (F) Rotary Encoders
- (G) Connectors/ Sockets
- (H) Temperature Controllers
- (I) SSRs / Power Controllers
- (J) Counters
- (K) Timers
- (L) Panel Meters
- (M) Tacho / Speed / Pulse Meters
- (N) Display Units
- (O) Sensor Controllers
- (P) Switching Mode Power Supplies
- (Q) Stepper Motors & Drivers & Controllers
- (R) Graphic/ Logic Panels
- (S) Field Network Devices
- (T) Software

MD5 Series

■ Caution During Use

1. For signal input

- ① Do not input CW, CCW signal at the same time in 2-pulse input method. Failure to follow this instruction may result in malfunction. It may not operate properly if another direction signal is inputted when one of CW or CCW is [H].
- ② When the signal input voltage is exceeded the rated voltage, connect additional resistance at the outside.

2. For RUN current, STOP current setting


- ① Set RUN current within the range of motor's rated current. Failure to follow this instruction may result in severe heat of motor or motor damage.
- ② If motor stops, switching for STOP current executed by the current down function. When hold off signal is [H] or current down function is OFF, the switching does not execute. (except MD5-ND14)
- ③ Use the power for supplying sufficient current to the motor.
- ④ Check the polarity of power before operating the unit. (only for MD5-HD14, HD14-2X/3X, ND14)

3. For cable connection

- ① Use twisted pair (over 0.2mm^2) for the signal cable which should be shorter than 2m.
- ② The thickness of cable should be same or thicker than the motor cable's when extending the motor cable.
- ③ Must separate between the signal cable and the power cable over 10cm.

4. For installation

- ① **The unit must be installed with heat protection. The conditions of ②, ③ should be satisfied.**
(×MD5-ND14)
- ② In order to increase heat protection efficiency of the driver, must install the heat sink close to metal panel and keep it well-ventilated.
- ③ Excessive heat generation may occur on driver. Keep the heat sink under 80°C when installing the unit. (at over 80°C , forcible cooling shall be required.)
- ④ If the unit is installed in distribution panel, enclosed space or place with heat, it may cause product damage by heat. Install a ventilation. (only for MD5-HF28)
- ⑤ For heat radiation of driver, install a fan as below figure. (distance between the ⑥ fan and the unit: approx. within 70mm, ⑦ min. airflow: $0.71\text{m}^3/\text{min}$ at least)
(only for MD5-HF28)



5. For using function selection DIP switches

- ① Be sure that the TEST switch is OFF before supplying the power. If the TEST switch is ON, the motor operates immediately and it may be dangerous. (except MD5-ND14)
- ② Do not change the pulse input method during the operation. It may cause danger as the revolution way of the motor is changed conversely.

6. This product may be used in the following environments.

- ① Indoor
- ② Altitude under 2000m
- ③ Pollution degree 2
- ④ Installation category II