

Autonics PANEL METER MT4N SERIES INSTRUCTION MANUAL



Thank you for choosing our Autonics products.
Please read the following safety considerations before use.

Safety Considerations

- Please observe all safety considerations for safe and proper product operation to avoid hazards.
- Safety considerations are categorized as follows:
 - Warning:** Failure to follow these instructions may result in serious injury or death.
 - Caution:** Failure to follow these instructions may result in personal injury or product damage.
- The symbols used on the product and instruction manual represent the following:
 - Δ symbol represents caution due to special circumstances in which hazards may occur.


Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, cranes/dissaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, fire, or economic loss.
- The unit must be installed on a device panel before use. Failure to follow this instruction may result in electric shock.
- Do not connect, repair, or inspect the unit while connected to a power source. Failure to follow this instruction may result in electric shock.
- Do not disassemble or modify the unit. Please contact us if necessary. Failure to follow this instruction may result in electric shock or fire.
- Check the terminal numbers before connecting the power source and measurement input. Failure to follow this instruction may result in fire.


Caution

- Do not use the unit outdoors. Failure to follow this instruction may result in electric shock or shorten the life cycle of the unit.
- When connecting the power input and relay output cables, use AWG20 (0.05mm²) cables and make sure to tighten the terminal screw bolt above 0.74N.m to 0.90N.m. Failure to follow this instruction may result in fire due to contact failure.
- Use the unit within the rated specifications. Failure to follow this instruction may result in electric shock or shorten the life cycle of the unit.
- Do not use loads beyond the rated switching capacity of the relay contact. Failure to follow this instruction may result in insulation failure, contact failure, contact bonding, relay damage, or fire.
- Do not use water or oil-based detergent when cleaning the unit. Use dry cloth to clean the unit.
- Do not use the unit where flammable or explosive gas, humidity, direct sunlight, radiant heat, vibration, and impact may be present. Failure to follow this instruction may result in fire or explosion.
- Keep dust and wire residue from flowing into the unit. Failure to follow this instruction may result in fire or explosion.
- Check the polarity of the measurement input contact before wiring the unit. Failure to follow this instruction may result in fire or explosion.


Ordering Information




Front Panel Identification



Panel Cut-Out



Terminal Connection



Prescale Function [PA1: H-5C/L-5C]


This function is to display setting (-1999 to 9999) of particular High/Low-limit value in order to display High/Low-limit value of measured input. If measured inputs are 'a' and 'b' and particular values are 'A' and 'B', it will display A/B as shown in graphs.



Error Display Function

Display	Description
HHHH	Flashes when measured input is exceeded the max. allowable input (110%).
LLLL	Flashes when measured input is exceeded the min. allowable input (-10%).
d-HH	Flashes when display input is exceeded H-5C setting value
d-LH	Flashes when display input is exceeded L-5C setting value
d-LL	Flashes when input frequency is exceeded the max. display value of measured range
a-HH	Flashes when it exceeds zero range (± 99)

Initialization Function



Display Cycle Delay Function [PA2: d1 St]

In some applications the measured input may fluctuate which in turn causes the display to fluctuate. By adjusting the display cycle delay function time at d1 St of parameter 2, the operator can adjust the display time within a range of 0.1 sec to 5 sec. For example, if the operator sets the display cycle time to 4.0 sec, the display value displayed will be the average input value over 4 sec. and also will show any changes if any every 4 sec.

Startup Compensation Timer Function [PA2: 5tRt]

This time function limits the operation of an output until the measured input (overvoltage or inrush current) is stable at moment of power on. All outputs are off during startup compensation time setting after power is applied. Setting range: 0.0 to 99.9 (Unit: sec.) Factory default: 0.0

User Manual For Communication

Visit our website (www.autonics.com) to download the user manual for communication of MT series.

The above specifications are subject to change and some models may be discontinued without notice.

Specifications

Model	MT4N-DV-E MT4N-DA-E	MT4N-AV-E MT4N-AA-E	MT4N-DV-4 MT4N-DA-4	MT4N-AV-4 MT4N-AA-4
Measurement input	DC voltage, ampere	AC voltage, ampere, Frequency	DC voltage, ampere	AC voltage, ampere, Frequency
Power supply	12-24VDC/AC		100-240VAC	
Allowable voltage range	90 to 110%		90 to 110%	
Power consumption	DC: 3W, AC: 5VA For MT4N-□-E5: DC: 5W, AC: 8VA		5VA	
Display method	7 Segment LCD display (Character height: 9mm)			
Display accuracy	23°C ± 5°C - DC Type: F.S. ± 0.1% rdg ± 2digit / AC Type: F.S. ± 0.3% rdg ± 3digit DC/AC Type: Within F.S. ± 0.3% rdg ± 3digit only for Current 5A terminal -10°C to 50°C - DC/AC Type: F.S. ± 0.5% rdg ± 3digit			
Max. allowable input	110% F.S. for each measured input range			
AD conversion method	Practical oversampling using successive approximation ADC			
Sampling cycle	DC type: 50ms, AC type: 16.6ms			
Max. display range	-1999 to 9999 (4digit)			
Preset output	• Relay output - Contact capacity: 125VAC 0.3A, 30VDC 1A/Contact composition: NO (1a) • NPN/PNP Open Collector output - 12-24VDC \pm 2V/50mA Max. (Load resistance)			
Sub output (Transmission output)	• RS485 communication output - Baud rate: 1200/2400/4800/9600, Communication method: 2-wire half duplex, Synchronous method: Sub-synchronization, Protocol: Modbus type • DC4-20mA output - Resolution: 12,000 division (Load resistance max. 600 Ω)			
Insulation resistance	Min. 20M Ω (at 500VDC megger)			
Dielectric strength	1000VAC for 1 minute (Between external terminal and case)		2000VAC for 1 minute (Between external terminal and case)	
Noise strength	\pm 2kV the square wave noise (pulse width: 1 μ s) by the noise simulator			
Vibration	Mechanical Malfunction 0.75mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 2 hours 0.5mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 10 minutes			
Shock	Mechanical Malfunction 100m/s ² (Approx. 10g) in X, Y, Z directions for 3 times 300m/s ² (Approx. 30g) in X, Y, Z directions for 3 times			
Environment	Ambient temperature -10 to 50°C, Storage: -20 to 60°C Ambient humidity 35 to 85%RH, Storage: 35 to 85%RH			
Insulation type	Double insulation or reinforced insulation (Mark: \square , Dielectric strength between the measuring input part and the power part: 1kV)			
Approval	CE			
Weight	Approx. 127g (approx. 64g)			

*1: The weight includes packaging. The weight in parentheses is for unit only.
*Environment resistance is rated at no freezing or condensation.

Specification Of Measured Input And Range [PA: i n r]


Type	Measured input and range	Input impedance	Display range [5tnd]	Prescale Display range [5tRt]
DC Volt	0-50V [50V]	434.35k Ω	0.00 to 50.00 (fixed)	0.00 to 50.00 (fixed)
	0-10V [10V]	434.35k Ω	0.00 to 10.00 (fixed)	0.00 to 10.00 (fixed)
	0-5V [5V]	43.35k Ω	0.000 to 5.000 (fixed)	0.000 to 5.000 (fixed)
	0-1V [1V]	43.35k Ω	0.000 to 1.000 (fixed)	0.000 to 1.000 (fixed)
	0-250mV [250mV]	2.15k Ω	0.0 to 250.0 (fixed)	0.0 to 250.0 (fixed)
	0-50mV [50mV]	2.15k Ω	0.0 to 50.0 (fixed)	0.0 to 50.0 (fixed)
	0-500 μ V [500 μ V]	0.1 Ω	0.0 to 500.0 (fixed)	0.0 to 500.0 (fixed)
DC Ampere	0-200mA [200mA]	0.1 Ω	0.0 to 200.0 (fixed)	0.0 to 200.0 (fixed)
	0-50mA [50mA]	1.1 Ω	0.0 to 50.00 (fixed)	0.0 to 50.00 (fixed)
	0-20mA [20mA]	1.1 Ω	4.00 to 20.00 (fixed)	4.00 to 20.00 (fixed)
	0-5mA [5mA]	101.1 Ω	0.000 to 5.000 (fixed)	0.000 to 5.000 (fixed)
	0-2mA [2mA]	101.1 Ω	0.000 to 2.000 (fixed)	0.000 to 2.000 (fixed)
	0-250V [250V]	1.109M Ω	0.0 to 250.0 (fixed)	0.0 to 250.0 (fixed)
	0-125V [125V]	1.109M Ω	0.0 to 125.0 (fixed)	0.0 to 125.0 (fixed)
AC Volt	0-50V [50V]	200k Ω	0.00 to 50.00 (fixed)	0.00 to 50.00 (fixed)
	0-25V [25V]	222k Ω	0.00 to 25.00 (fixed)	0.00 to 25.00 (fixed)
	0-5V [5V]	22k Ω	0.000 to 5.000 (fixed)	0.000 to 5.000 (fixed)
	0-2.5V [2.5V]	22k Ω	0.000 to 2.500 (fixed)	0.000 to 2.500 (fixed)
	0-0.5A [0.5A]	0.01 Ω	0.000 to 5.000 (fixed)	0.000 to 5.000 (fixed)
	0-2.5A [2.5A]	0.01 Ω	0.000 to 2.500 (fixed)	0.000 to 2.500 (fixed)
	0-500mA [500mA]	0.1 Ω	0.0 to 500.0 (fixed)	0.0 to 500.0 (fixed)
AC Ampere	0-250mA [250mA]	0.1 Ω	0.0 to 250.0 (fixed)	0.0 to 250.0 (fixed)
	0-100mA [100mA]	0.5 Ω	0.0 to 100.0 (fixed)	0.0 to 100.0 (fixed)
	0-50mA [50mA]	0.5 Ω	0.0 to 50.00 (fixed)	0.0 to 50.00 (fixed)

Monitoring Max./Min. Display Value Function [PA: HPEL/LPEL, PA 2: PELL]

It monitors max./min. value of display value based on the current displays value and then displays the data at HPEL, LPEL of parameter 0. Set the delay time (0 to 30 sec) at PELL of parameter 2 in order to prevent malfunction caused by initial overcurrent or overvoltage, when monitoring the peak value. Delay time is 0 to 30 sec. and it starts to monitor the peak value after the set time. When pressing any one of the [MODE] keys at HPEL, LPEL of parameter 0, the monitored data is initialized.

Current Output (DC4-20mA) Scale Adjustment Function [PA 2: F5-H/F5-L]

It sets current output for the display value at the output current DC 4-20mA.
It sets display value for 4mA at F5-L and 20mA at F5-H and the range between F5-H and F5-L should be 10% F.S. (When it sets under 10% F.S., it changed as over 10% F.S. automatically.) Preset display value is fixed to output as 4mA at under F5-L and 20mA at over F5-H.



AC Frequency Measurement Function [PA 1: d1 SP]

It measures input signal frequency when it is AC input. It uses fixed decimal point [PA 1: dot]. measured range can be changed by setting and measured range of decimal point position is as below chart. It is available to adjust the upper gradient at [PA 1: nbH] and [PA 1: nbL]. In order to measure frequency normally, input signal, over 10% F.S. of the measured range, should be supplied. Please select the proper point of measurement terminal.

Measured range

Decimal point position	0.000	0.00	0.0	0
Measurement range	0.100 to 9.999Hz	0.10 to 99.99Hz	0.1 to 999.9Hz	1 to 9999Hz

*Accuracy of frequency measurement:
Below 1kHz, F.S. \pm 0.1rdg \pm 2digit.
From 1kHz to 10kHz, F.S. \pm 0.3rdg \pm 2digit.
10kHz to 100Hz, Gradient adjustment of high value
100Hz to 1000Hz, [Index adjustment of nbH]

Error Correction Function [PA 1: i nbH/i nbL]

It corrects display value error of measured input.
nbH: ± 99 (Adjust deviation of low value)
nbL: 5.000 to 0.100 (Correct gradient (%) of high value)
Display values = (Measured value \times nbH) \div nbL
When the measured range is 0 to 500V, and the display range is 0 to 500.0, if the low value is "12" to 0V input, set -12 as the nbL value to display "00" by adjusting the offset of the low value.
The display value to the 500V measured input varies by adjusting the offset of the low value. If this display value is "50 00", calculate 500.0/50.0 (the desired display value/the display value), and set the 0.998 correction value as the nbH to display "5000" by adjusting the gradient of the high value.
*The offset correction range of nbL is within -99 to 99 for "D", "d" digit regardless of decimal point.

Zero Adjustment Function

It adjusts the display value of the optional configured input value as zero by force, zero point error can be adjusted with 3 ways as below.

When zero point adjustment with front key and Hold terminal is finished normally, zero point of measurement terminal is displayed and the adjusted value is saved in nbL automatically.

Operation	Input correction value	Front key	Input external signal
PR 1	Direct input correction value method at nbL	Press both [MODE], [F5]	Short-circuit external Hold terminal no. 11, 12 over min. 50m.

*Refer to description "Error correction function", "Error display function", "Parameter 2" for function and error.

Gradient Correction Function [PA 1: i nbH]

It corrects the gradient of prescale value and display value.
(Figure 1) Display value Y can be adjusted as α , β times against X input value by correction function [nbH] and used as correction function of max. display value [H-5C]. Adjustment range is 0.100 to 5.000 and multiply current gradient.

Example: To display "3.000" in DC 200mV input for measured input specification as 0 to 1V.

① Select 0-1VDC for measured input in Parameter 1.
② Standard specification in input: 0-1VDC and 1.000 therefore it has to be 15,000[H-5C] for 1VDC (Input) in order to display 3.000 for 200mVDC (input). But it is unable due to setting range is 9.999.

③ In this case, please check below chart. Please set as nbH = H \times H-5C = 15,000

Setting method	H-5C	L-5C	nbH	Note
①	Unavailable	0.000	1.000	---
②	7.500	0.000	2.000	---
③	5.000	0.000	3.000	In this case, any setting methods display the same display value.
④	3.750	0.000	4.000	---
⑤	3.000	0.000	5.000	---

Preset Output Mode [PA 2: oU Lc / oU Lk]


Mode	Output operation	Operation
oFF	OUT1 output OUT2 output	No output
Hi	OUT1.H OUT1 output	Period ON: Display value \geq OUT1.H Period OFF: Display value $<$ OUT1.H-Hys
Lo	OUT1.L OUT1 output	Period ON: Display value \leq OUT1.L Period OFF: Display value $>$ OUT1.L+Hys
HL	OUT1.H OUT1.L OUT1 output	Period ON: Display value \leq OUT1.L or Display value \geq OUT1.H Period OFF: Display value $>$ OUT1.L+Hys or Display value $<$ OUT1.H-Hys
HL-G	OUT1.H OUT1.L OUT1 output	Period ON: OUT1.L \leq Display value \leq OUT1.H+Hys Period OFF: Display value $>$ OUT1.H-Hys or Display value $<$ OUT1.L+Hys

*Set output mode separately for each OUT1/OUT2.
*OUT1/OUT2 are operated individually depending on output operation mode.
*Setting value mode of parameter group is displayed depending on output operation mode.
*GO outputs when the period both OUT1/OUT2 are off. (NPN/PNP Open collector output type)

Parameter

Parameter	Display	Function	Note	
PR 1 (Parameter 1)	INr	Input type	Selectable RMS/AVG in AC type Available AC type only.	
	di SP	Input range	Selectable of input range	
	d1 SP	Display	Selectable of display type	
	5tnd	Standard	Selectable of standard	
	F r E 9	Frequency	Standard scale display Available AC type only.	
	5tRL	Scale	Selectable of scale	
	H-5C	High scale	Select max. value of display range	
	L-5C	Low scale	Select min. value of display range	
	dot	Dot	Select decimal point position	
	dJnb	Display unit lamp	Select display unit	
	inbH	Input bias high	Correct High-limit gradient of display value	
	inbL	Input bias low	Correct Low-limit gradient of display value	
	inbE	Input bias exponent	Select display index of frequency mode	
	oU Lk	Out1 type	Select output mode of OUT1	
	oU Lc	Out2 type	Select output mode of OUT2	
	PR 2 (Parameter 2)	HYS1	OUT1 hysteresis	Select hysteresis of OUT1 Within 1 to F.S. 10% (Variable depending on set of input range and prescale.)
HYS2		OUT2 hysteresis	Select hysteresis of OUT2	
5tRt		Startup compensation time	Select startup compensation time	
PELk		Peak time	Select monitoring delay time for peak (sec)	
d1 St		Display time	Select sampling time (sec)	
Colr		Color	Select color	
E r o		Zero key	Select usage of front side zero adjustment key	
PA 0 (Parameter 0)		E r o	Event input	Select external terminal (11, 12) function
		F5-H	Full scale high	Select high-limit value output position of PV output
		F5-L	Full scale low	Select low-limit value output position of PV output
		Rd5	Address	Select communication address
		bPs	Baud rate	Select baud rate (bps)
		P r s	Parity bit	Select parity bit
		Stp	Stop bit	Select stop bit
		r5tL	Response waiting time	Select response waiting time
		LoL	Lock	Enable lock status
	oU H	OUT1 high preset	Select value of OUT1 High-limit output	
	oU L	OUT1 low preset	Select value of OUT1 Low-limit output	
	oU2H	OUT2 high preset	Select value of OUT2 High-limit output	
	oU2L	OUT2 low preset	Select value of OUT2 Low-limit output	
	HPEL	High peak	Max. value by data monitoring	
	LPEL	Low peak	Min. value by data monitoring	


Parameter Setting




Change The Parameter Setting Value

- Advance to the parameter to be changed when pressing [MODE] key continuously in RUN mode and releasing [MODE] key at the parameter.
- When pressing [MODE] key in each parameter, the initial mode of the parameter is displayed.
- When pressing one of the [MODE] keys in display mode, the saved setting value is displayed.
- Change the setting value by [MODE] or [MODE] key when setting value flashes.
- When confirming the setting value with [MODE] key, the changed setting value flashes twice and enters into the next setting.
- It returns RUN mode from parameter by pressing [MODE] key for 3 sec.


Parameter 0



Parameter 1



Parameter 2



Cautions During Use

- Please use the terminal (M3.5, Max. 6.0mm) when connecting the AC power supply.
- Please use separated line from high voltage line or power line in order to avoid inductive noise.
- Please install power switch or circuit breaker in order to cut off the power supply.
- The switch or circuit breaker should be installed near by users for safety.
- Be sure to avoid using the following unit near by machinery making strong high frequency noise. (High frequency welder & Sewing machine, High capacity SCR unit etc.)
- When input is applied, if "HHHH" or "LLLL" is displayed, there is some problem with measured input, please check the line after power off.
- Noise inflowing from power line can cause serious problem for D.P.M. (Digital Panel Meter) driving by AC power supply. Even though