



# Ø16 Key Selector Switches

## Ø16 Rectangular Key Selector Switches (S16KRT Series)


Type	Appearance	Operating position	Model	Contact block	LED block
				C contact	DC voltage
Extended		2-position, spring return key removal: left	<b>S16KRT-1AKC</b>	1	—
			<b>S16KRT-1AK2C</b>	2	
		2-position, maintained key removal: left	<b>S16KRT-2AKC</b>	1	
			<b>S16KRT-2AK2C</b>	2	
		2-position, maintained key removal: left + right	<b>S16KRT-2BKC</b>	1	
			<b>S16KRT-2BK2C</b>	2	
		2-position, maintained key removal: right	<b>S16KRT-2DKC</b>	1	
			<b>S16KRT-2DK2C</b>	2	
		3-position, spring return two-way key removal: center	<b>S16KRT-3EK2C</b>	2	
3-position, maintained key removal: left	<b>S16KRT-4AK2C</b>	2			
3-position, maintained key removal: left + right	<b>S16KRT-4BK2C</b>	2			
3-position, maintained key removal: left + center + right	<b>S16KRT-4CK2C</b>	2			
3-position, maintained key removal: right	<b>S16KRT-4DK2C</b>	2			

※ The control unit, contact blocks, LED blocks are sold separately.

(control unit: bold letters, contact block: regular letters)

※ Connect up to 2 contact blocks. Connect the contact blocks only on the right and left side slots. It will not operate if connected to the center slot.

### • Dimensions



※ For panel cut-out dimensions, please refer to page A-48.



# Ø16 Key Selector Switches

Control Switches

Ø16

Ø22/25

Ø30

□30

Push Button Switches

Round

Square

Rectangular

Selector Switches

Round

Square

Rectangular

Key Selector Switches

Round

Square

Rectangular

Double Push Button Switches

Mushroom-head Push Button Switches

Emergency Switches

Pilot Lights

Accessories


Buzzers

Type	Appearance	Operating position	Model	Contact block		LED block
				C contact		DC voltage
Extended	 S16KRT-4EK□  	3-position, maintained key removal: center		<b>S16KRT-4EK2C</b>	2	—
		3-position, maintained key removal: center + right		<b>S16KRT-4FK2C</b>	2	
		3-position, maintained key removal: left + center		<b>S16KRT-4GK2C</b>	2	
		3-position, spring return from right key removal: left		<b>S16KRT-5AK2C</b>	2	
		3-position, spring return from right key removal: center		<b>S16KRT-5EK2C</b>	2	
		3-position, spring return from right key removal: left + center		<b>S16KRT-5GK2C</b>	2	
		3-position, spring return from left key removal: right		<b>S16KRT-6DK2C</b>	2	
		3-position, spring return from left key removal: center		<b>S16KRT-6EK2C</b>	2	
		3-position, spring return from left key removal: center + right		<b>S16KRT-6FK2C</b>	2	

※ The control unit, contact blocks, LED blocks are sold separately.  
(control unit: bold letters, contact block: regular letters)

※ Connect up to 2 contact blocks. Connect the contact blocks only on the right and left side slots.  
It will not operate if connected to the center slot.

• Dimensions




※ For panel cut-out dimensions, please refer to page A-48.

# Ø16 Panel Cut-out Dimensions

## Ø16 Panel Cut-out Dimensions

(unit: mm)

Type			A	B	Panel Cut-out Dimensions
Push Button Switches	Round (S16PR Series)		20	21	
	Square (S16PRS Series)		20	21	
	Rectangular (S16PRT Series)		25	21	
Selector Switches	Round (S16SR Series)		20	21	
	Square (S16SRS Series)		20	21	
	Rectangular (S16SRT Series)		25	21	
Key Selector Switches	Round (S16KR Series)		20	21	
	Square (S16KRS Series)		20	21	
	Rectangular (S16KRT Series)		25	21	
Mushroom-head Push Button Switches (S16BR Series)			24	24	
Emergency Switches (S16ER Series)			40	40	
Pilot Lights	Round (L16RR Series)		20	21	
	Square (L16RRS Series)		20	21	
	Rectangular (L16RRT Series)		25	21	



# A Accessories

## Common Accessories

### Contact Blocks and LED Blocks for Ø16 Control Switches


#### Ordering Information

SA	16	CB	W	
Item				Applied switches
Type				LED color <sup>※1</sup>
LED block				
CB <sup>※2</sup>				Contact block
L5				LED block
L12				
L24				
16				For Ø16 control switches
SA				Switch Accessories
				R Red
				B Blue
				G Green
				Y Yellow
				W White
				B contact (normally closed)
				C contact (normally open, normally closed)
				5VDC
				12VDC
				24VDC

※1. Only for LED blocks.

※2. Only for Ø16 emergency switches.

- **Contact block and LED block removal**  
Separate the unit using a flat-head (-) screwdriver.



Item	Appearance	Model	Type	Features
Contact block		SA16-CB	B contact (normally closed)	For Ø16 emergency switches
		SA16-CC	C contact (normally open, normally closed)	—
LED block		SA16-L5□ (5VDC) SA16-L12□ (12VDC) SA16-L24□ (24VDC)	DC voltage type	Diverse, vibrant, high luminance LEDs (red, blue, green, yellow, white)

# A Accessories

## Locking Handle for Switches

Applied switches	Appearance	Model	Note
Ø16		SA16-LH	For locking switch nuts behind the panels

## Accessories By Item

Item	Appearance	Model	Dimensions	Note
Lens remover for Ø16 push button control switches or pilot lights		SA16-RM		Lens remover for push button control switches or pilot lights