


DIGITAL KEYPAD

This chapter describes the various controls and indicators found on the digital keypad/display PU01. The information in this chapter should be read and understood before performing the start-up procedures described in the chapter of parameter settings.

- ↳ Description of the Keypad
- ↳ Description of Display
- ↳ Keypad Operation Modes & Programming Steps

VFD-PU01 Dimensions: mm (inch)



Description of the Digital Keypad VFD-PU01

