



Analog Input Module

Instruction Sheet

1 WARNING


- Always read this manual thoroughly before using the DVP04AD-H.
- The DC input power must be disconnected before any maintenance.
- This is an OPEN-TYPE built-in DVP04AD-H, and the DVP04AD-H is certified to meet the safety requirements of IEC 61131-2 (UL 508) when installed in the enclosure to avoid high temperature, high humidity, excessive vibration, corrosive gases, liquids, airborne dust or metallic particles. Also, it is equipped with protective methods such as some special tool or key to open the enclosure, so as to avoid the hazard to users and the damage to the DVP04AD-H.
- Do not connect the AC power to any of the input/output terminals, as it might cause damage to the DVP04AD-H. Make sure that all the wiring is well conducted prior to power on.
- Do not touch the internal circuit for at least 1 minute after the power supply is disconnected.
- Make sure that the DVP04AD-H is properly grounded (⊕), to avoid any electromagnetic noise.

2 INTRODUCTION


2.1 Model Explanation and Peripherals

- Thank you for choosing DELTA's PLC DVP Series. The analog input module receives external 4-point analog signal input (voltage or current) and transforms it into 14 bits digital signal. The analog input module of DVP04AD-H series can read/write the data of analog input module by using commands FROM / TO via DVP-PLC EH Series MPU program. There are 49 CR(Control Register) in each module and there are 16 bits in each register.
- DVP04AD-H analog input module can update software version by RS-485 communication.
- Users can select input from voltage or current via wiring. Voltage input range is ±10V DC (resolution is 1.25 mV). Current input range is ±20 mA (resolution is 5 μA).


■ Nameplate Explanation



■ Model Explanation




2.2 Product Profile and Outline



- | | |
|---|---|
| 1. DIN rail location (35mm) | 6. Terminals |
| 2. Mounting hole to connect expansion unit/expansion module | 7. Expansion hole of the expansion unit mounting pins |
| 3. Model name | 8. Terminal layout |
| 4. Indicator LED for power, error and run state | 9. Mounting port to connect expansion unit/expansion module |
| 5. DIN rail clip | |

2.3 External wiring



- Note 1: Please isolate analog input and other power wiring.
 - Note 2: If connect to current signal, please short circuit between V+ and I+ terminals.
 - Note 3: If noise is too loud, please connect FG to grounding.
 - Note 4: Please connect ⊕ terminal of power module and ⊕ terminal of analog input module to system earth point and make system earth point be grounding or connects to machine cover.
 - Note 5: If wave of input terminal of loaded is too big that noise interferes wiring, please connect capacitance with 0.1~0.47μF 25V.
- Warning: DO NOT wire to the No function terminal ●.

3 STANDARD SPECIFICATIONS

3.1 Function Specifications

Analog/ Digital (4A/D) module	Voltage input	Current input
Power supply voltage	24 VDC(20.4VDC~28.8VDC) (-15%~+20%)	
Analog input channel	4 channel / each module	
Analog input range	±10V	±20 mA
Digital conversion range	±8000	
Resolution	14 bits(1 _{LSB} =1.25 mV)	13 bits (1 _{LSB} =5 μA)
Input impedance	200 KΩ or above	250 Ω
Overall accuracy	±0.5% of full scale of 25°C (77°F) ±1% of full scale during 0~55°C (32~131°F)	
Response time	3 ms x channels	
Isolation Method	It has isolation between digital area and analog area. There is no isolation among channels.	
Absolute input range	±15 V	±32 mA
Digital data format	2's complementary of 16-bit, 13 Significant Bits	
Average function	Yes (CR#2~CR#5 can be set and setting range is K1~K4096)	
Self diagnose function	Upper and lower bound detection / channels	
Communication mode (RS-485)	Yes, there are ASCII/RTU modes, communication rate can be 4800 /9600 /19200 /38400 /57600 /115200. Communication format of ASCII mode is 7Bit, even bit, 1 stop bit (7 E 1). Communication format of RTU mode is 8Bit, even bit, 1 stop bit (8 E 1). When connecting to PLC MPU in series, RS-485 can't be used.	
Connect to DVP-PLC MPU in series	The input point of the first analog extension unit it connects from the near to the distant is from 0 to 7. The Max. is 8 modules and it won't waste digital I/O point.	

3.2 Other Specification

Power Specification	
Max. Rated Consuming Power	24 VDC(20.4VDC~28.8VDC) (-15%~+10%), 2W, supply from external power
Environment Condition	
Environment Condition	It is the same with DVP-PLC MPU.
Spec. of Prevent Static Electricity	All places between terminal and grounding

4 CR (Control Register)

CR No.	RS-485 Parameter address	Latched	Register name	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
#0	H 4000	○	R	Model type															
#1	H 4001	○	R/W	Input mode setting															
#2	H 4002	○	R/W	CH1 average times															
#3	H 4003	○	R/W	CH2 average times															
#4	H 4004	○	R/W	CH3 average times															
#5	H 4005	○	R/W	CH4 average times															
#6	H 4006	×	R	average value of CH1 input signal															
#7	H 4007	×	R	average value of CH2 input signal															
#8	H 4008	×	R	average value of CH3 input signal															
#9	H 4009	×	R	average value of CH4 input signal															
#10 ~ #11				Reserved															
#12	H 400C	×	R	present value of CH1 input signal															
#13	H 400D	×	R	present value of CH2 input signal															

DVP04AD-H analog signal input module				Explanation															
CR No.	RS-485 Parameter address	Latched	Register name	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
#14	H 400E	×	R	present value of CH3 input signal															
#15	H 400F	×	R	present value of CH4 input signal															
#16 ~ #17				Reserved															
#18	H 4012	○	R/W	To adjust OFFSET value of CH1															
#19	H 4013	○	R/W	To adjust OFFSET value of CH2															
#20	H 4014	○	R/W	To adjust OFFSET value of CH3															
#21	H 4015	○	R/W	To adjust OFFSET value of CH4															
#22 ~ #23				Reserved															
#24	H 4018	○	R/W	To adjust GAIN value of CH1															
#25	H 4019	○	R/W	To adjust GAIN value of CH2															
#26	H 401A	○	R/W	To adjust GAIN value of CH3															
#27	H 401B	○	R/W	To adjust GAIN value of CH4															
#28 ~ #29				Reserved															
#30	H 401E	×	R	Error status															
#31	H 401F	○	R/W	Communication address setting															
#32	H 4020	○	R/W	Communication baud rate setting															
#33	H 4021	○	R/W	Reset to factory setting and set characteristics adjustable priority															
#34	H 4022	○	R	Software version															
#35~#48				System used															

○ means latched.
× means not latched.
R means can read data by using FROM command or RS-485.
W means can write data by using TO command or RS-485.
LSB (Least Significant Bit): 1. Voltage input: 1_{LSB}=10V/8000=2.5mV. 2. Current input: 1_{LSB}=20mA/4000=5μA.

Explanation:

- CR#0: The content of CR#0 is model type, user can read the data from program to know if there is extension module.
 - CR#1: CR#1 is used to set 4 inner channels working mode of analog input module. Every channel has four modes to set and can be set individually. For example: if setting CH1 to mode 0 (b2~b0=000), CH2 to mode 1 (b5~b3=001), CH3: mode2 (b8~b6=010), CH4: mode 3 (b11~b9=011). It needs to set CR#1 to H0688 and the upper bit (b12~b15) will be reserved. The factory setting of CR#1 is H0000.
 - CR#2 ~ CR#5: it is used to set average times of CH1~CH4. Setting range is K1~K4096 and factory setting is K10.
 - CR#6 to CR#9 are the average value that calculates according to the value that is set in CR#2~CR#5 (average time of CH1~CH4 input signal). For example, if CR#2 (the average times of CH1) is 10, it will calculate the average of CH1 input signal every 10 times.
 - CR#10, CR#11, CR#16, CR#17, CR#22, CR#23, CR#28, CR#29 reserved.
 - CR#12 ~ CR#15: display present value of CH1~CH4 input signal.
 - CR #18~ CR #21: the content is the value of adjusting OFFSET value of CH1~CH4 if analog input voltage or current is 0 after it transfers from analog to digital. Voltage setting range: -5V~+5V(-4000_{LSB}~+4000_{LSB}). Current setting range: -20mA~+20mA (-4000_{LSB}~+4000_{LSB}).
 - CR #24~ CR #27: means analog input voltage or current when conversion value from analog signal to digital is 4000. Voltage setting range: -4V~+20V(-3200_{LSB}~+16000_{LSB}). Current setting range: -16mA~+52mA(-3200_{LSB}~+10400_{LSB}). But it needs to notice that GAIN VALUE - OFFSET VALUE = +800_{LSB}~+12000_{LSB} (voltage) or +800_{LSB}~+6400_{LSB} (current). When this value under this range, the resolution of the input signal will be thin and the variation of value will be larger. When this value exceeds this range, the resolution of input signal will be thick and the variation of value will be smaller.
 - CR#30 is fault code. Please refer to the following chart.
- | Fault description | Content | b15~b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|-----------------------------|-----------|----------|----|----|----|----|----|----|----|----|
| Power source abnormal | K1(H1) | Reserved | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| Analog input value error | K2(H2) | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| Setting mode error | K4(H4) | | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| Offset/Gain error | K8(H8) | | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 |
| Hardware malfunction | K16(H10) | | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| Digital range error | K32(H20) | | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 |
| Average times setting error | K64(H40) | | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
| Command error | K128(H80) | | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
- Note: Each fault code will have corresponding bit (b0~b7). Two or more faults may happen at the same time. 0 means normal and 1 means having fault.
- CR#31: it is used to set RS-485 communication address. Setting range is 01~255 and factory setting is K1.

