
# DIN W48×H48mm Star-Delta Timer

### Features

- Realization of wide range of power supply
  : 100-240VAC 50/60Hz, 24-240VDC universal
- Wide range of setting time and switching time
  - T1 (setting time): Selectable 0.5 to 100sec
  - T2 (switching time): Selectable 0.05, 0.1, 0.2, 0.3, 0.4, 0.5sec
- Simple setting time, switching time operation
- Easy to check output status by LED display
- Application: Starting large capacity motors










# Ordering Information



※8-pin socket (PG-08, PS-08(N)) is sold separately.

## Specifications

Model		AT8SDN				
Function		Star-Delta timer				
Control time setting range**1		0.5 to 100 sec				
Power supply		100-240VAC~ 50/60Hz, 24-240VDC== universal				
Allowable voltage range		90 to 110% of rated voltage				
Power consumption		Max. 3.2VA (100-240VAC∼), Max. 1.5W (24-240VDC≕)				
Return time		Max. 100ms				
Timing operation		Power ON start type				
Control output	Contact type	从 contact: SPST (1a), Δ contact: SPST (1a)				
	Contact capacity	250VAC~ 5A, 30VDC== 5A resistive load				
Titolay	Mechanical	Min. 10,000,000 operations				
	Electrical	Min. 100,000 operations (250VAC 5A resistive load)				
Repeat error		Max. ±0.2 % ±10ms				
↓Setting error		Max. ±5% ±50ms				
Voltage error		Max. ±0.5%				
Temperature error		Max. ±2%				
从-Δ Switching time error		Max. ±25%				
Insulation resistance		Over 100MΩ (at 500VDC megger)				
Dielectric strength		2,000VAC 50/60Hz for 1 minute				
Noise immunity		±2kV the square wave noise (pulse width: 1µs) by the noise simulator				
Vibration	Mechanical	0.75mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 1 hours				
Vibration	Malfunction	0.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 10 min				
Shock	Mechanical	300m/s² (approx. 30G) in each X, Y, Z direction for 3 times				
SHOCK	Malfunction	100m/s² (approx. 10G) in each X, Y, Z direction for 3 times				
Environment	Ambient temperature	-10 to 55°C, storage: -25 to 65°C				
Liiviioiiiieiit	Ambient humidity	35 to 85%RH				
Approval		C € c <b>PN</b> us				
Accessory		Bracket				
Unit weight		Approx. 90g				


X1: Refer to time specifications for control time setting range.

K-68

XEnvironment resistance is rated at no freezing or condensation.


# **Star-Delta Analog Timer**

### Connections




Dimensions


48




O Bracket



Panel cut-out



# Unit Description



(A) Photoelectric Sensors

(B) Fiber Optic

> (C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure

> (F) Rotary

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(unit: mm)

(H) Temperature

(I) SSRs / Power Controllers

(J) Counters

(K) Timers

> L) anel leters

(M) Tacho / Speed / Pulse Meters

(N) Display Units

> o) ensor

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

(S) Field Network Devices

(T) Software

Autonics K-69

# ■ Time Specifications


#### 1. T1 (setting time)

Time range	Time unit	Time setting range		
0.5		0.5 to 5sec		
1	10SEC	1 to 10sec		
5		5 to 50sec		
10		10 to 100sec		

#### 2. T2 ( 人 - △ switching time)


(unit: sec)

Display	A	F	F1	С	D	I
T2 $(\lambda-\Delta)$ switching time)	0.05	0.1	0.2	0.3	0.4	0.5



## Output Operation Mode

 $\lambda$  contact will be ON as soon as power is supplied,  $\lambda$  contact will be OFF when T1 setting time is up then  $\Delta$  contact will be ON after T2 switching time is up.  $\Delta$  contact will be OFF when cut off the power at the status of  $\Delta$  contact is ON.




ЖТ1: Setting time (¿contact operation time)

 $XT2: A-\Delta$  Swtiching time (A and  $\Delta$  contact are OFF when power is ON.)

# ■ Proper Usage

- Follow instructions in 'Proper Usage'. Otherwise, it may cause unexpected accidents.
- When supplying or turning off the power, use a switch or etc. to avoid chattering.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- In order to avoid leakage current flowing, connect resistance and condenser as (Figure 2).
  If connect as (Figure 1), it may cause malfunction due to leakage current.



- Keep away from high voltage lines or power lines to prevent inductive noise.
- In case installing power line and input signal line closely, use line filter or varistor at power line and shielded wire at input signal line.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
- Change setting time(T1),  $\bot$ - $\triangle$  switching time or etc. after turning off the power of the timer.
- This product may be used in the following environments.
  - ①Indoors (in the environment condition rated in 'Specifications')
  - ②Altitude max. 2,000m
  - ③Pollution degree 2
  - (4) Installation category II

K-70